

# GASTEC Instructions for No. 6L Water Vapour Detector Tube

## FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

### ! WARNING:

1. Use only Gastec detector tubes in a Gastec pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

### ! CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.


1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

### △ NOTES: For maintaining performance and reliability of the test results, observe the following.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
4. The shelf life and storage condition of the tube are marked on the label of the tube box.
5. Keep the detector tube temperature lower than the gas temperature.

**APPLICATION OF THE TUBE:** Use this tube for detecting water vapour in the air or in industrial areas and for determining the environmental atmospheric condition.

**SPECIFICATION:** (Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



|                          |   |            |
|--------------------------|---|------------|
| Measuring Range          | (0.05) - 1 mg/L   | 1 - 2 mg/L |
| Number of Pump Strokes   | 1   | 1/2        |
| Stroke Correction Factor | 1   | 2          |
| Sampling Time            | 30 seconds  | 15 seconds |
| Detecting Limit          | 0.03 mg/L (n = 1)                                       |            |
| Colour Change            | Yellow → Purple   |            |
| Reaction Principle       | $H_2O + Mg(ClO_4)_2 \rightarrow Mg(ClO_4)_2 \cdot H_2O$ |            |

**Coefficient of Variation: 10% (for 0.05 to 0.2 mg/L), 5% (for 0.2 to 1 mg/L)**

**\*\* Shelf Life: Please refer to the validity date printed on the tube box.**

**\*\* Store the tubes in a dark and cool place.**

## CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Calibration of the Gastec detector Tube No.6L is based on a tube temperature of 20°C (68°F) and not the temperature of the gas being sampled, and normal atmospheric pressure.

**Temperature:** No correction is required.  
**Pressure:** To correct for pressure, use the formula below:  

$$\frac{\text{Tube Reading (mg/L)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

## MEASUREMENT PROCEDURE:

1. For checking the leakage of the pump, insert a freshly sealed detector tube into the pump. Follow the instructions provided with the pump operation manual.
2. Break the tips off the fresh detector tube with the tube tip breaker in the pump.
3. Insert the tube into the pump inlet with the arrow ( **G** ) on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 30 seconds and confirm the completion of the sampling.
6. For measurements higher than 1 mg/L, prepare a fresh tube and perform a half pump stroke.
7. Read the concentration level at the interface where the stained reagent meets the unstained reagent.
8. If necessary, multiply the readings by the correction factors of the pump strokes and atmospheric pressure respectively.

## INTERFERENCES:

| Substance        | Concentration  | Interference        | Interference gas only |
|------------------|----------------|---------------------|-----------------------|
| Alcohols         |                | Unclear demarcation | Purple(whole layer)   |
| Aldehydes        |                | Unclear demarcation | Purple(whole layer)   |
| Ammonia          | $\geq 10$ ppm  | Unclear demarcation | Yellowish green       |
| Ketones          |                | Unclear demarcation | Purple(whole layer)   |
| Nitriles         |                | Unclear demarcation | Purple(whole layer)   |
| Hydrocarbons     |                | No                  | No discoloration      |
| Nitrogen dioxide |                | No                  | No discoloration      |
| Sulphur dioxide  | $\geq 100$ ppm | +                   | No discoloration      |

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

**INSTRUCTIONS ON DISPOSAL:** The reagent of the tube does not use toxic substances. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

**WARRANTY:** If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation  
 8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan  
<http://www.gastec.co.jp/>  
 Telephone +81-467-79-3910 Fax +81-467-79-3979

IM006LE2  
 Printed in Japan  
 09J/D