

GASTEC Instructions for No. 91L Formaldehyde Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

⚠ WARNING:

- Use only Gastec detector tubes in a Gastec pump.
- Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

⚠ CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.


- When breaking the tube ends, keep away from eyes.
- Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
- The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

⚠ NOTES: For maintaining performance and reliability of the test results, observe the following.

- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
- Use this tube within the relative humidity range of 0 - 90%.
- This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE: Use this tube for detecting formaldehyde in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION: (Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	0.1 - 5.0 ppm	5.0 - 40 ppm
Number of Pump Strokes	5	1
Stroke Correction Factor	1	8
Sampling Time	1.5 minutes per pump stroke	
Detecting Limit	0.05 ppm (n = 5)	
Colour Change	Yellow → Reddish Brown	
Reaction Principle	$3\text{HCHO} + (\text{NH}_2\text{OH})_3\text{H}_3\text{PO}_4 \rightarrow \text{H}_3\text{PO}_4$ $\text{H}_3\text{PO}_4 + \text{Base} \rightarrow \text{Phosphoric Acid Salt}$	

Coefficient of Variation: 10% (for 0.1 to 1.0ppm), 5% (for 1.0 to 5.0 ppm)

**** Shelf Life: Please refer to the validity date printed on the tube box.**

**** Store the tubes at 10°C (50°F) or below in a refrigerator.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Temperature: Correct for temperature with the table below.


Temperature °C (°F)	0(32)	5(41)	10(50)	15(59)	20(68)	25(77)	30(86)	35(95)	40(104)
Correction Factor	1.5	1.35	1.2	1.1	1.0	0.9	0.85	0.75	0.7

Humidity: No correction is required.

Pressure: To correct for pressure, use the formula below:

$$\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

MEASUREMENT PROCEDURE:

- For checking the leakage of the pump, insert a freshly sealed detector tube into the pump. Follow the instructions provided with the pump operation manual.
- Break the tips off the fresh detector tube with the tube tip breaker in the pump.
- Insert the tube into the pump inlet with the arrow () on the tube pointing toward the pump.
- Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
- Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 1.5 minutes and confirm the completion of the sampling. Repeat the above sampling procedure four more times.
- For measurements higher than 5.0 ppm, prepare a fresh tube and perform a one-pump stroke.
- Read the concentration level at the interface where the stained reagent meets the unstained reagent.
- If necessary, multiply the readings by the correction factors of the temperature, pump strokes and atmospheric pressure respectively.

INTERFERENCES:

Substance	Concentration	Interference	Interference gas only
Aldehydes		+	Reddish brown
Ketones		+	Reddish brown
Acid Gases		+	Red
Organic acids		No	No

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Ceiling by ACGIH (2009) : 0.3 ppm

Explosive range: 7.0 - 73%

APPLICATION FOR OTHER SUBSTANCES:

Substance	Correction Factor	No. of Pump Strokes	Measuring Range
Diisobutyl ketone	5.8	4	0.58 - 29 ppm
Methaldehyde	0.65	3	0.065 - 3.25 ppm
Propionaldehyde	7.6	1	0.76 - 38 ppm

Cyclohexanone (ppm)	10 20 50 100 200 300 400 470
91L Tube Reading (n = 1/2)	0.2 0.5 1.0 2.0 3.0 4.0 5.0

Benzaldehyde (ppm)	4 10 20 30 40 60 80 92
91L Tube Reading (n = 1)	0.2 0.5 1.0 2.0 3.0 4.0 5.0

CORRECTION FACTOR: Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. The correction factor is a number which is multiplied by the concentration as interpreted from the colour on the detector tube. The correction factor may also be presented as a chart on the tube if the correction relationship is nonlinear. Therefore, make use of the correction factor/chart measurement ranges as a reference. Moreover, this factor may vary slightly between production batches. For a more precise factor please contact your Gastec distributor.

INSTRUCTIONS ON DISPOSAL: The reagent of the tube does not use toxic substances. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY: If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation

8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan

http://www.gastec.co.jp/

Telephone +81-467-79-3910 Fax +81-467-79-3979

IM0091LE2

Printed in Japan

09J/D