

GASTEC instructions for No.151L Acetone Detector Tube

FOR SAFE OPERATION :

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

⚠ WARNING :

1. Use only Gastec detector tubes in a Gastec Pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties

⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.

1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

⚠ NOTES : For maintaining performance and reliability of the test results.


1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the "INTERFERENCES".
5. Shelf life and storage condition of the tube is marked on the label of the box of tube.

APPLICATION OF THE TUBE :

Use this tube for the detection of Acetone in air or the industrial areas and environmental atmospheric condition.

SPECIFICATION :

(As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



| Measuring Range | 50 - 4000 ppm | 4000 - 12000 ppm |
|------------------------|---|------------------|
| Number of Pump Strokes | 2 | 1 |
| Correction Factor | 1 | 3 |
| Sampling Time | 2 minutes per pump stroke | |
| Detecting Limit | 5 ppm (n = 2) | |
| Colour Change | Yellow → Red | |
| Reaction Principle | Acetone reacts with hydroxylamine phosphate to produce phosphoric acid which discolors pH indicator to red. | |

Coefficient of Variation : 15% (for 50 to 500 ppm), 10% (for 500 to 4000 ppm)

**** Shelf Life : Please refer to the Validity Date printed on the box of tube.**

**** Store the tubes in the refrigerator to keep at 10°C (50°F) or below.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

Temperature : Since the tube is affected by the temperature, correct for temperature by the table below.

Humidity : No correction is required.

Pressure : To correct for pressure, multiply by the tube reading by

$$\frac{\text{Tube Reading (\%)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

| Tube Reading (ppm) | True Concentration (ppm) | | | | | | | | |
|--------------------|--------------------------|------------|-------------|-------------|-------------|-------------|-------------|-------------|--------------|
| | 0°C (32°F) | 5°C (41°F) | 10°C (50°F) | 15°C (59°F) | 20°C (68°F) | 25°C (77°F) | 30°C (86°F) | 35°C (95°F) | 40°C (104°F) |
| 4000 | 6800 | 6000 | 5200 | 4600 | 4000 | 3600 | 3200 | 2800 | 2100 |
| 3000 | 5400 | 4600 | 4000 | 3500 | 3000 | 3600 | 2200 | 1800 | 1300 |
| 2000 | 3900 | 3350 | 2850 | 2400 | 2000 | 1600 | 1250 | 900 | 620 |
| 1000 | 2400 | 2000 | 1650 | 1300 | 1000 | 740 | 520 | 360 | 250 |
| 500 | 1600 | 1300 | 1000 | 720 | 500 | 380 | 290 | 220 | 160 |
| 200 | 580 | 400 | 300 | 240 | 200 | 160 | 120 | 100 | 80 |
| 100 | 260 | 200 | 150 | 120 | 100 | 85 | 70 | 55 | 40 |
| 50 | 130 | 100 | 80 | 65 | 50 | 43 | 35 | 28 | 20 |

MEASUREMENT PROCEDURE :

1. For leak tight check of the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube in the tube tip breaker of the pump.
3. Insert the tube securely into pump inlet with arrow (➔) on the tube pointing toward pump.
4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
5. Pull handle all the way out until it locks on 1 pump stroke (100ml). Wait 2 minutes and confirm the completion of the sampling. Repeat the above sampling procedure one more time.
6. For higher than 4000 ppm measurement, prepare fresh tube and take 1 pump stroke.
7. Read concentration at the interface of the stained-to-unstained reagent.
8. If correction is needed, multiply the correction factors of temperature, pump strokes and pressure.

INTERFERENCES :

| Substance | Concentration | Interference | Changes colour by itself to |
|------------------------|---------------|--------------|-----------------------------|
| Acrolein, Acetaldehyde | ≥1/10 | + | Red |
| Aromatic hydrocarbons | | No | No |
| Methyl isobutyl ketone | | + | Red |
| Methyl ethyl ketone | | + | Red |

The table of this interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or our distributors in your territory.

APPLICATION FOR OTHER SUBSTANCES :

Tube 151L can also be used for other substances as below :

| Substance | Correction Factor | No. of Pump Strokes | Measuring Range |
|---------------------|-------------------|---------------------|-----------------|
| Methyl ethyl ketone | 0.42 | 5 | 21 - 1680 ppm |
| Propionaldehyde | 0.47 | 2 | 24 - 1880 ppm |

CORRECTION FACTOR :

Detector tubes are primary designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For more precise factor please contact your Gastec distributor.

DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2005) : 500 ppm

Threshold Limit Value-Short Term Exposure Limit by ACGIH (2005) : 750 ppm

Explosive Range : 2.1 - 13 %

DISPOSAL INSTRUCTION : Reagent of the tube does not use toxic substances. When dispose of the tube regardless of whether used or unused, follow the rules and regulations of the local government.

WARRANTY : If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation
 8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan
<http://www.gastec.co.jp/>
 Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM00151LE1
 Printed in Japan
 08D1Z