


Ethyl ether (C₂H₅)₂O
 Humidity Correction 5)

no.161L



Performance

Measuring Range	10 to 400 ppm	400 to 1200 ppm
Number of Pump Strokes	2	1
Correction Factor	1	3
Sampling Time	4 minutes per pump stroke	
Detecting Limit	2 ppm (n=2)	
Color Change	Yellow → Pale blue	
Reaction Principle	Ethyl ether reduces chromic acid to produce pale blue discoloration.	
Coefficient of Variation	10% (for 10 to 100 ppm), 5% (for 100 to 400 ppm)	
Shelf Life	2 Years	
Corrections for temperature & humidity	Temperature correction is necessary	
Store the tubes at cool and dark place.		

Possible coexisting substances and their interferences (NOTE)

Substance	Concentration	Interference	Change color by itself
Alcohols	-	Plus error	Produce pale blue discoloration
Esters	-	Plus error	Produce pale blue discoloration
Ketones	-	Plus error	Produce pale blue discoloration

Calibration gas generation Diffusion tube method

TLV-TWA	TLV-STEL	Explosive range
400ppm	500ppm	1.9 to 4.8%

Nextteq LLC – 8406 Benjamin Rd., Suite J, Tampa FL 33634, USA

Phone (toll free): 877-312-2333 Fax (toll free) 877-312-2444

Policy Statement and Legal Notices

Nextteq is Gastec's Exclusive U.S. Master Wholesale Distributor. Gastec tubes and pumps are manufactured by the Gastec Corporation.