

GASTEC Instructions for No.19LA Arsine Detector Tube

FOR SAFE OPERATION :

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

⚠ WARNING:

1. Use only Gastec detector tubes in a Gastec Pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.

1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

⚠ NOTES : For maintaining performance and reliability of the test result.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the "INTERFERENCES".
5. Shelf life and storage condition of the tube is marked on the label of the box of tube.

APPLICATION OF THE TUBE :

Use this tube for the detection of Arsine in air or industrial areas and environmental atmospheric condition.

SPECIFICATION :

(As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Detecting Layer

Measuring Range	0.04 - 0.1 ppm	0.1 - 1.5 ppm	1.5 - 2.4 ppm	2.4 - 10 ppm
Number of Pump Stroke	10	5	3	1
Correction Factor	0.4	1	1.6	6.7
Sampling Time	1.5 minutes per pump stroke			
Detecting Limit	0.02 ppm (n = 10)			
Colour Change	Yellow → Red			
Reaction Principle	AsH ₃ + Indicator → Chemical reaction compound			

Coefficient of Variation : 10% (for 0.1 to 0.5 ppm), 5% (for 0.5 to 1.5 ppm)

**** Shelf Life : Please refer to the Validity Date printed on the box of tube.**

**** Store the tubes under dark and cool place.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :


Temperature : No correction is required.

Humidity : No correction is required.

Pressure : To correct for pressure, multiply the tube reading by

$$\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

MEASUREMENT PROCEDURE :

1. For leak checking of the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube by bending each tube end in the tube tip breaker of the pump.
3. Insert the tube securely into pump inlet with arrow  on the tube pointing toward pump.
4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
5. Pull the handle all the way out until it locks on 1 pump stroke (100ml). Wait 1.5 minutes and confirm the completion of the sampling. Repeat the above sampling procedure 4 more times.
6. Read concentration at the interface of the stained to unstained reagent.
7. For lower than 0.1 ppm measurement, repeat the above sampling procedure 5 more times until the stain attains to the first calibration mark. For higher than 1.5 ppm measurement, prepare fresh tube and take 1 or 3 pump strokes.
8. If correction is needed, multiply the correction factors of pump stroke and pressure.

INTERFERENCES :

Substance	Concentration	Interference	Changes colour by itself to
Hydrogen chloride		No	No
Diborane		No	No
Phosphine	≥ 1/10	+	Red

The table of this interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2005) : 0.05 ppm.

DISPOSAL INSTRUCTION :

This tube contains a small amount of mercury. When dispose of the tube regardless of whether used or unused, follow the rules and regulations of the local government.

WARRANTY :

If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation
8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan

<http://www.gastec.co.jp/>

Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM0019LAE1
Printed in Japan
06C1Z