

GASTEC Instructions for Carbon Dioxide Detector No. 2HH Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

! WARNING:

1. Use only Gastec detector tubes in a Gastec pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

! CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.


1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

△ NOTES: For maintaining performance and reliability of the test results, observe the following.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
5. The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE: Use this tube for detecting carbon dioxide in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION: (Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	2.5 - 5%	5 - 40%
Number of Pump Strokes	1	1/2
Stroke Correction Factor	1/2	1
Sampling Time	45 seconds per pump stroke	
Detecting Limit	0.04% (n = 1)	
Colour Change	Orange → Yellow	
Reaction Principle	$\text{CO}_2 + 2\text{KOH} \rightarrow \text{K}_2\text{CO}_3 + \text{H}_2\text{O}$	

Coefficient of Variation: 10% (for 5 to 10 %), 5 % (for 10 to 40 %)

**** Shelf Life: Please refer to the validity date printed on the tube box.**

**** Store the tubes in a dark and cool place.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Temperature: No correction is required.
Humidity: No correction is required.
Pressure: To correct for pressure, use the formula below:

$$\frac{\text{Tube Reading (\%)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

MEASUREMENT PROCEDURE:

1. For checking the leakage of the pump, insert a freshly sealed detector tube into the pump. Follow the instructions provided with the pump operation manual.
2. Break the tips off the fresh detector tube with the tube tip breaker in the pump.
3. Insert the tube into the pump inlet with the arrow (**G**) on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide mark "50" on the pump body with the red guide mark on the handle.
5. Pull the handle 1/2 stroke until it locks on the half-pump stroke (50mL). Wait 45 seconds and confirm that the sampling has completed.
6. For smaller measurements less than 5%, prepare a fresh tube and perform one pump stroke.
7. Read the concentration level at the interface where the stained reagent meets the unstained reagent.
8. If necessary, multiply the readings by the correction factors of the pump strokes and atmospheric pressure respectively.

INTERFERENCES:

Substance	Concentration	Interference	Interference gas only
Ammonia	≧ 8%	No	No discoloration
Hydrogen chloride	≧ 3%	No	White (≧ 4000 ppm)
Chlorine	≧ 1%	No	White (≧ 1000 ppm)
Hydrogen sulphide	≧ 1/15	No	Pale yellow (≧ 1200 ppm)
Sulphur dioxide	≧ 2%	No	Pale yellow (≧ 2400 ppm)
Nitrogen dioxide	≧ 1/5	No	Pale yellow (≧ 50 ppm)
Ethanol	≧ 7%	No	Pale yellow (≧ 2%)
Acetic acid	≧ 2%	No	Pale yellow (≧ 4500 ppm)
Trimethylamine	≧ 10%	No	No discoloration
Carbon monoxide, Nitric oxide		No	No discoloration
Ethylene, Propane		No	No discoloration

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2009): 5,000 ppm
 Threshold Limit Value-Short Term Exposure Limit by ACGIH (2009): 30,000 ppm

INSTRUCTIONS ON DISPOSAL: The reagent of the tube does not use toxic substances. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY: If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation
 8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan
<http://www.gastec.co.jp/>
 Telephone +81-467-79-3910 Fax +81-467-79-3979

IM002HHE1
 Printed in Japan
 09/J/D