

1. PERFORMANCE

- 1) Measuring range : 5-50 ppm
Number of pump strokes : 1 (100mℓ)
- 2) Sampling time : 2 minutes/1 pump stroke
- 3) Detectable limit : 2 ppm
- 4) Shelf life : 1 year (Necessary to store in a refrigerated place ; 0 ~ 10 °C)
- 5) Operating temperature : 0 ~ 40 °C
- 6) Reading : Direct reading from the scale calibrated by 1 pump stroke
- 7) Colour change : White → Purple


2. RELATIVE STANDARD DEVIATION

RSD-low : 15 % RSD-mid. : 10 % RSD-high : 10 %

3. CHEMICAL REACTION

Chlorine is produced by decomposing with an Oxidizer.

By reacting between this Chlorine and 3, 3¹-Dimethylnaphthidine, Nitroso-compound is produced.



4. CALIBRATION OF THE TUBE

DIFFUSION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	ppm	Coexistence
Nitrogen oxides	Similar stain is produced.		Higher readings are given.
Halogens	〃		〃
Halogenated hydrocarbons	〃		〃
Hexane	The accuracy of readings is not affected.	100	Lower readings are given.