



## Performance

When used, these tubes are to be connected.

Measuring range	0.1 to 0.2 ppm	0.2 to 6.0 ppm	6.0 to 18.0 ppm
Number of pump strokes	4 (400 ml)	2 (200 ml)	1 (100 ml)
Correction factor	1/2	1	3
Sampling time	8 min	4 min	2 min

Detecting limit : 0.05 ppm (4 pump strokes)

Colour change : Yellow → Pink

Corrections for temperature & humidity : Unnecessary

Relative standard deviation : 10 % (for 0.2 to 2.0 ppm), 5 % (for 2.0 to 6.0 ppm)

Shelf life : 3 years

## Reaction principle

Pretreatment tube :  $\text{CH}_2:\text{CHCN} + \text{Cr}^{6+} + \text{H}_2\text{SO}_4 \rightarrow \text{HCN}$

Detector tube :  $2\text{HCN} + \text{HgCl}_2 \rightarrow 2\text{HCl}$

$\text{HCl} + \text{Base} \rightarrow \text{Chloride}$

## Possible coexisting substances and their interferences

Substance	Concentration	Interference	Changes colour by itself to
Acetone cyanohydrin		+	} Pink
Nitriles ( $\geq \text{C}_3$ )		+	
Alcohols, Esters, Ketones		No	} No
Aromatic hydrocarbons		No	
Hydrogen chloride		No	
Hydrogen cyanide		No	

Chlorine, hydrogen chloride, hydrogen cyanide, nitric acid and water vapour are trapped in the white layer in the pretreatment tube.

## Other substances measurable with this detector tube

Substance	Correction	No. of pump strokes	Measuring range
Butyronitrile	Factor : 30	1	6 to 180 ppm
2-Methyl-3-butenenitrile	Factor : 2.0	2	0.4 to 12.0 ppm
2-Pentenenitrile	Factor : 1.2	2	0.24 to 7.2 ppm
3-Pentenenitrile	Factor : 2.0	2	0.4 to 12.0 ppm

## Calibration gas generation

Diffusion tube method