


**Tetrachloroethylene**  $\text{Cl}_2\text{C}:\text{CCl}_2$ 

NO.133L

**Performance**

<b>Measuring Range</b>	1 to 2ppm	2 to 25ppm	25 to 75ppm
<b>Number of Pump Strokes</b>	2	1	1/2
<b>Correction Factor</b>	1/2	1	3
<b>Sampling Time</b>	1.5 minutes per pump stroke		
<b>Detecting Limit</b>	0.4 ppm (n=2)		
<b>Color Change</b>	Yellow → Pink		
<b>Reaction Principle</b>	Tetrachloroethylene is decomposed by nascent oxygen by oxidizing agent to liberate hydrogen chloride which discolors indicator to reddish purple.		
<b>Coefficient of Variation</b>	10% (for 2 to 5 ppm), 5% (for 5 to 25 ppm)		
<b>Shelf Life</b>	2 Years		
<b>Corrections for temperature &amp; humidity</b>	Temperature correction is necessary		
<b>Store the tubes in the refrigerator to keep at 10 °C (50°F) or below.</b>			

**Possible coexisting substances and their interferences** (NOTE)

Substance	Concentration	Interference	Change color by itself
Nitric Oxide, Nitrogen dioxide	-	No effect	No discoloration
Hydrogen chloride, Chlorine, Bromine	-	Plus error	Produce reddish pink stain
Acetone	200 ppm	No effect	No discoloration
Unsaturated Halogenated HCs	-	Plus error	Produces reddish pink stain
Aromatic hydrocarbons	100ppm	Minus error	No discoloration

**Other substance measurable with this detector tube**

Substance	Correction Factor	Pump Strokes	Measuring Range
Pentachloroethane	20	1	20 to 500 ppm

**Calibration gas generation** Diffusion tube method

TLV-TWA	TLV-STEL	Explosive range
25ppm	100ppm	-



© 2002 Nextteq LLC

---

Nextteq LLC – 8406 Benjamin Rd., Suite J, Tampa FL 33634, USA

Phone (toll free): 877-312-2333 Fax (toll free) 877-312-2444

[Policy Statement](#) and [Legal Notices](#)

Nextteq is Gastec's Exclusive U.S. Master Wholesale Distributor. Gastec tubes and pumps are manufactured by the Gastec Corporation.