

Carbon disulfide CS₂**NO.13M****Performance**

Measuring Range	20 to 50 ppm	50 to 1600 ppm	1600 to 4000 ppm
Number of Pump Strokes	2	1	1/2
Correction Factor	0.4	1	2.5
Sampling Time	3 minutes per pump stroke		
Detecting Limit	10 ppm (n=2)		
Color Change	Purple → Yellow		
Reaction Principle	Carbon disulfide reacts with primary tube to produce intermediate product which changes the indicator of analyzer tube to yellow.		
Coefficient of Variation	10% (for 50 to 400 ppm), 5% (for 400 to 1600 ppm)		
Shelf Life	3 Years		
Corrections for temperature & humidity	Temperature correction is necessary		
Store the tubes at cool and dark place.			

Possible coexisting substances and their interferences (NOTE)

Substance	Concentration	Interference	Change color by itself
Sulfur dioxide	-	Plus error	Discolor yellow stain
Hydrogen sulfide	-	Plus error	Discolor yellow stain
Lower class HCs	1000 ppm	Plus error	Discolor yellow stain

Calibration gas generation Diffusion tube method

TLV-TWA	TLV-STEL	Explosive range
10ppm	-	1.3 to 50%

Nextteq is Gastec's Exclusive U.S. Master Wholesale Distributor. Gastec tubes and pumps are manufactured by the Gastec Corporation.