

GASTEC Instructions for No. 1LK Carbon Monoxide Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

! WARNING:

1. Use only Gastec detector tubes in a Gastec pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

! CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.


1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

△ NOTES: For maintaining performance and reliability of the test results, observe the following.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
5. This tube may produce double layered colour stain. When pale green stain is found, read concentration at the end of pale green layer. When there is no pale green layer found, read concentration at the end of pale brown stain.
6. The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE: Use this tube for detecting carbon monoxide in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION: (Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	5 - 100 ppm	100 - 300 ppm	300 - 600 ppm
Number of Pump Strokes	3	1	1/2
Stroke Correction Factor	1	3	6
Sampling Time	2 minutes per pump stroke		1 minute
Detecting Limit	0.5 ppm (n = 3)		
Colour Change	White → Pale brown / Pale green (dual layers)		
Reaction Principle	$5CO + I_2O_5 + H_2S_2O_7 \rightarrow I_2$		

Coefficient of Variation: 10% (for 5 to 10 ppm), 5% (for 10 to 100 ppm)


**** Shelf Life: Please refer to the validity date printed on the tube box.**

**** Store the tubes in a dark and cool place.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Temperature:	No correction is required.
Humidity:	No correction is required.
Pressure:	To correct for pressure, use the formula below: $\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$

MEASUREMENT PROCEDURE:

1. For checking the leakage of the pump, insert a freshly sealed detector tube into the pump. Follow the instructions provided with the pump operation manual.
2. Break the tips off the fresh detector tube with the tube tip breaker in the pump.
3. Insert the tube into the pump inlet with the arrow () on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait 2 minutes and confirm the completion of the sampling. Repeat the above sampling procedure two more times
6. For measurements higher than 100 ppm, prepare a fresh tube and perform one or a half pump strokes.
7. Read the concentration at the interface of the stained-to-unstained reagent. This tube may produce double layered colour stain. When pale green stain is found, read concentration at the end of pale green layer. When there is no pale green layer found, read concentration at the end of pale brown stain,
8. If necessary, multiply the readings by the correction factors of the pump strokes and atmospheric pressure respectively.

INTERFERENCES:

Substance	Concentration	Interference	Interference gas only
Hydrogen	≤ 10%	—	No discoloration
Ammonia		No	No discoloration
Carbon dioxide		No	No discoloration
Hydrogen sulphide		No	No discoloration
Nitrogen oxides		No	No discoloration
Sulphur dioxide		No	No discoloration

Most of organic gases are trapped in the pretreatment layer. If the pretreatment reagent is entirely consumed, a higher reading will be given.

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2009): 25 ppm
Explosive range: 12.5 - 74%

INSTRUCTIONS ON DISPOSAL: The reagents of the tubes use a small amount of hexavalent chromium and selenium. When disposing of the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY: If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation
8-8-6 Fukayanaka, Ayase-City, 252-1195, Japan
<http://www.gastec.co.jp/>
Telephone +81-467-79-3910 Fax +81-467-79-3979

IM001LKE3
Printed in Japan
10C/D