

Gemini® Twin Port Sorbent Tube Sampler



Zefon's Gemini Twin-Port Sorbent Tube Sampler can be used with the Escort ELF, or just about any other sampling pump able to pull a flow rate of 1.5LPM at 25" of water backpressure. It offers increased flexibility and control in gathering samples through sorbent tubes. If air is being sampled for two or more contaminants, the Gemini can draw samples at independent flow rates through tubes containing different sorbents. In situations where a single contaminant is being sampled, sampling on two tubes of the same type can be done simultaneously at different flow rates. This type of sampling protects against breakthrough which occurs when a tube's sampling capacity is exceeded because the concentration of a contaminant is higher than anticipated. Duplicate sampling at the same flow rate can also be done to achieve better results.

Features:

- Valved mechanism allows flow control down to .001 lpm
- Control the flow rate of each port independently
- Includes tube covers to fit both large and small tube sizes



Ordering Information

Part Number	Description	Price
497697	Gemini® Twin Port Sampling Kit — includes: Gemini Sampler, tube protectors, Y-connectors, clips and carrying case.	\$ 285.00
ST-001	Charcoal Sampling Tubes (150mg), 50 tubes	38.00

Gemini is a registered trademark of Zefon International.



5350 SW 1st Lane, Ocala, Florida 34474 USA
 Tel: 01 352 854 8080; Fax: 01 352 854 7480
 www.zefon.com

Sampling Equipment Specialists