

1. PERFORMANCE


- 1) Measuring range : 100-3000 ppm
Number of pump strokes 1 (100mℓ)
- 2) Sampling time : 1 minute/1 pump stroke
- 3) Detectable limit : 10 ppm (100mℓ)
- 4) Shelf life : 2 years
- 5) Operating temperature : 0 ~ 40 °C
- 6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
- 7) Reading : Direct reading from the scale calibrated by 1 pump stroke
- 8) Colour change : White → Dark brown

2. RELATIVE STANDARD DEVIATION

RSD-low : 10 % RSD-mid. : 10 % RSD-high : 10 %

3. CHEMICAL REACTION

Iodine pentoxide is reduced.



4. CALIBRATION OF THE TUBE

GAS CHROMATOGRAPHY

5. INTERFERENCE AND CROSS SENSITIVITY

TEMPERATURE CORRECTION TABLE

Tube Readings (ppm)	Corrected Concentration (ppm)				
	0 °C (32 °F)	10 °C (50 °F)	20 °C (68 °F)	30 °C (86 °F)	40 °C (104 °F)
3000	4000	3500	3000	2800	2600
2500	3300	2900	2500	2300	2200
2000	2700	2300	2000	1900	1800
1500	2000	1700	1500	1400	1300
1000	1300	1100	1000	970	940
500	500	500	500	500	500
300	300	300	300	300	300
100	100	100	100	100	100