

1. PERFORMANCE


- 1) Measuring range : 0.01-1.4 %
Number of pump strokes : 2 (200ml)
- 2) Sampling time : 3 minutes/2 pump strokes
- 3) Detectable limit : 10 ppm
- 4) Shelf life : 3 years
- 5) Operating temperature : 0 ~ 40 °C
- 6) Reading : Direct reading from the scale calibrated by 2 pump strokes
- 7) Colour change : Orange → Brownish green

2. RELATIVE STANDARD DEVIATION

RSD-low : 10 % RSD-mid. : 5 % RSD-high : 5 %

3. CHEMICAL REACTION

Potassium dichromate is reduced.



4. CALIBRATION OF THE TUBE

GAS CHROMATOGRAPHY

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	ppm	Coexistence
Acetylene		3%	Whole reagent is discoloured to Brown and higher readings are given.
Propane		0.2%	∕
Other organic gases or vapours except Halogenated hydrocarbons	Similar stain is produced	50	Higher readings are given.