

## Performance

Measuring range	2.5 to 5 ppm	5 to 50 ppm	50 to 100 ppm
Number of pump strokes	4(400 ml)	2 (200 ml)	1(100 ml)
Correction factor	1/2	1	2
Sampling time	6 min	3 min	1.5 min

 $\begin{array}{lll} \mbox{Detecting limit:} & \mbox{0.5 ppm } (\mbox{4 pump strokes}) \\ \mbox{Colour change:} & \mbox{White} \rightarrow \mbox{Pale yellow} \\ \end{array}$ 

Corrections for temperature & humidity : Unnecessary

Relative standard deviation: 10 % (for 5 to 10 ppm), 5 % (for 10 to 50 ppm)

Shelf life: 3 years

## Reaction principle

 $2PH_3 + 6HgCl_2 + 3H_2O \rightarrow Hg_3P_2 \cdot 3HgCl_2 \cdot 3H_2O + 6HCl$ 

## Possible coexisting substances and their interferences

Substance	Concentration	Interference	Changes colour by itself to	
Hydrogen sulphide	≥ 10 ppm	+	Dark brown	
Arsine	≥ 20 ppm	+	Brown	
Hydrogen selenide	≥ 20 ppm	+	J DIOWII	

## Calibration gas generation

High pressure gas cylinder method